

## **SMART LOCK DO'S AND DON'TS**

	Description
1.	Ensure Arrow points towards direction of handle
2.	Ensure Split Pin is put into Spindle – failure to do so could result in disengagement of external handle
3.	Only Use (4x) AAA Alkaline Batteries with not less than 2000mAh
4.	Ensure installation is as per Machining details
5.	DO NOT squash connecting cable – this may cause power drain and significantly shorten life of batteries

